



vaggaro®
of Sweden

USER MANUAL



IMPORTANT!

Please read this manual carefully before use.
Keep it for future reference.

Vaggaro – Combination furniture

Vaggaro – a modular foldable baby furniture that quickly becomes indispensable for both big and little family members. It provides a sense of security to the baby who can always remain close, and at the same height as the parents. Its low weight of 1.6 kg makes it easy to move around both inside and outside your home. The Vaggaro-line consists of a Cradle, a Bouncer and a High chair – all mounted on the same patented folding frame. The only thing that needs to be replaced as your baby grows are the textile modules.

Table of contents

Vaggaro components	3
Unfolding	4
Folding	5
Height adjustment	6
Assembling Vaggaro-Cradle	7
Assembling Vaggaro-Baby Bouncer	8
Assembling Vaggaro-High Chair	10
General information	11
Certifications and testing	11
Technical information Vaggaro-Cradle	12
Technical information Vaggaro-Baby Bouncer	13
Technical information Vaggaro-High Chair	14

For further information and instruction videos - go to www.vaggaro.com

Vaggaro components



1. Long arms

2. Short arms


3. Legs

4. Fixing knob – height adjustment and stretching of textile module

5. Lock button - folding and height adjustment

6. Suspension rope

7. Textile module



Unfolding

Vaggaro is set up in three steps.



1. Begin by grabbing two opposite legs and pull them outward. Continue with the other two legs until all four legs have reached desired height. (The legs are automatically being locked in the position you release them.)



2. Assemble textile module, see separate sections for each textile module.



3. Stretch and stabilize the textile module by turning the fixing knob clockwise. *(Tightening of the fixing knob also locks the lock button, preventing unintentional folding.)*

Folding

Vaggaro folds easily in 3 steps.



1. Loosen the fixing knob until there is no tension on the knob.

(NOTE You don't need to take off the textile module from any of Vaggaro's models when you fold the furniture. The fabric folds with the frame.)



2. Turn the frame upside down and grab the leg closest to the lock button with your right hand. Grab the opposite leg with your left hand.



3. Press and hold the lock button with your thumb. Then fold the frame by folding the legs outwards/downwards.

TIP! To make pressing of the button easier, bring the opposite legs together while you're pressing the button.

Height adjustment

The automatic locking mechanism makes it easy for you to adjust the height on your Vaggaro. Follow the instructions in the section Unfolding (page 4), but instead of fully unfolding the legs, stop at the desired height.



Assembling Vaggaro-Cradle



1. Raise the frame to the desired height and loosen the fixing knob so that the arms can move freely.



2. Attach the higher/front part of the textile module to the long arms and attach the lower/rear part on the short arms. Make sure the buttons are fitted through the eyelets as illustrated



3. Stretch and stabilize the textile module by tightening the fixing knob.

Assembling Vaggaro-Baby Bouncer



1. Raise the frame to the desired height and loosen the fixing knob so that the arms can move freely.



2. Start by attaching the top part of the bouncer on the long arms. Make sure the fabric is fitted correctly on the buttons as illustrated.




3. Attach and adjust the rope.
 - a. Attach the rope as illustrated. It is important to pull the rope through the hole from the correct direction to adjust the bouncer's angle.
 - b. Tie a knot at least 5 cm from the end of the rope after the rope has been pulled through the second eyelet in the fabric. Repeat on the other side.



4. Adjusting bouncer's shape and angle.

You can easily choose desired angle by adjusting the rope length between the frame and the fabric. Longer rope creates a more upright sitting position.

In order to adjust the shape of the bouncer pull the rope as illustrated. Repeat on the other side.



5. Stretch and stabilize the textile module by tightening the fixing knob.

NOTE! Do not use too upright sitting position before your child has a good head control.

Assembling Vaggaro-High Chair



1. Raise the frame to the desired height and loosen the fixing knob so that the arms can move freely.



2. Attach the higher/rear part of the textile module on the long arms and the lower/front part on the short arms. Make sure the fabric is fitted correctly on the buttons as illustrated.



3. Stretch textile module and stabilize the frame by tightening the fixing knob.



4. Fasten safety belt in the front or rear loops of the chair, depending on the child's size.

General Information



© Copyright Vaggaro, Sweden

Vaggaro is developed and designed by Swedish engineer, Fredrik Bergling.

Vaggaro is patent and design protected, see www.vaggaro.com

Contact Vaggaro:

email: info@vaggaro.com

phone: +46 70 432 44 82

address: Vaggaro, Ebbas väg 28, 26372 Skäret, Sweden

Certifications and testing

Vaggaro complies with the highest European safety standards for children's furniture.

Tested and approved according to the European standards by

Teknologisk Institut Denmark www.teknologisk.dk/

(EN 1466:2014, EN 12790:2009, EN 14988-1/2 :2006+A1:2012)

Technical information Vaggaro-Cradle

Fabric

100% cotton

Frame

Weight: 1,5 kg

Dimensions: (height x length x width) Highest usage mode: 85x57x57cm

Folded position: 14x59x14cm

Material: aluminum, zinc and oak

Cradle

Weight: 1,8 kg

Dimensions: (height x length x width) Highest usage mode: 80x80x47cm

Folded position: 14x59x14cm

Textile module material: 100% cotton canvas

Care instructions: Cradle Textile Module

100% cotton

Wash separately at 40°C, do not tumble dry, iron at medium heat (do not iron labels).



Warning

Please read this user guide carefully before using the furniture.

Keep these instructions for future use.

- Designed for children from birth up to a maximum weight of 9 kg.
- When children can sit, kneel or pull themselves up, the cradle should not be used.
- Never carry the cradle with a child in it.
- Never use cradle on an elevated surface.
- Only use cradle on a horizontal surface.
- Do not let small children to play unattended near the cradle.
- Check the cradle regularly and do not use it if any components are damaged or missing.
- Do not use accessories or spare parts that are not approved by the manufacturer.
- Never leave your child unattended.
- Never place the cradle near open flames or other sources of heat.
- To reduce the risk of SIDS (Sudden Infant Death Syndrome), pediatricians recommend that healthy infants should be placed on their backs for sleep, unless otherwise advised by your doctor.
- Do not place the cradle near curtains, belts, cords or other objects that may get into the cradle.

Technical information Vaggaro-Baby Bouncer

Fabric

100% cotton

Frame

Weight: 1,5 kg

Dimensions: (height x length x width) High-

est usage mode: 85x57x57cm

Folded position: 14x59x14cm

Material: aluminum, zinc and oak

Baby Bouncer

Weight: 1,8 kg

Dimensions: (height x length x width)

Highest usage mode: 80x66x41 cm

Folded position: 14x59x14cm

Material: 100% cotton canvas

Care instructions: Baby Bouncer Textile module

100% cotton.

Wash separately at 40°C, do not tumble dry, iron at medium heat (do not iron labels).

Washing can cause wooden buttons to fade. To regain their original shine, rub them with vegetable oil.



Warning

Please read this user guide carefully before using the furniture.

Keep these instructions for future use.

- This baby bouncer is designed for children up to 9 kg of weight.
- Never leave your child unattended.
- Do not use the bouncer once your child can sit up unaided.
- Always use the restraint system.
- Do not place the bouncer on elevated or uneven surface such as a table.
- Do not use the bouncer if all parts are not properly fastened.
- Do not allow other children to play with or around the bouncer.
- Never carry, lift or adjust the bouncer with a child in it.
- The bouncer is not intended for prolonged periods of sleep. The bouncer does not replace a cradle or a bed. If a child wants to sleep, you should put him or her in a suitable cradle or bed.
- **Fall hazard:** child's activity may move the bouncer.
- **Choking hazard:** Never use the bouncer on a soft surface (bed, sofa, cushion) as it can tumble over and cause suffocation.
- Check the baby bouncer regularly and do not use it if any of the components are damaged or missing.
- Do not use accessories or spare parts that are not approved by the manufacturer.

Technical information Vaggaro-High Chair

Fabric

100% polyester

Frame

Weight: 1.5 kg

Dimensions: (height x length x width) Highest usage mode: 85x57x57cm

Folded position: 14x59x14cm

Material: aluminum, zinc and oak

High chair

Weight: 1.6 kg

Dimensions: (height x length x width)

Highest usage mode: 85x22x22cm

Folded position: 14x59x14cm

Material: 100% easy clean polyester

Care instructions: High Chair Textile module

100% Polyester, stain resistant and quick drying.

It can easily be washed in the sink or in machine at 40°C. Do not iron, it doesn't require ironing. Washing can cause wooden buttons to fade. To regain their original shine, rub them with vegetable oil.



Warning

Please read this user guide carefully before using the furniture.

Keep these instructions for future use.

- This chair is designed for children up to 24 months, weighing up to 15kg who can sit up unassisted.
- Never leave your child unattended.
- Always make sure the chair is steady and the fabric is fitted correctly before use.
- Make sure fixing knob is properly tightened.
- Always use safety belt.
- Do not use components other than those approved by the manufacturer.
- Never carry the chair with a child in it.

Fire hazard

- Never use the chair near the open flames or other sources of heat.

Fall hazard

- Child's activity may move the chair.
- Never use chair on elevated surface. Use it only on even floor.
- Never use chair on soft surface (bed, sofa, cushion).
- Never place a child in the chair before the furniture is locked and secured.
- Never adjust the height of the chair with a child in it.
- This chair should only be assembled by adults.
- Check the chair regularly and do not use it if any of the components are damaged or missing.



vaggaro[®]
of Sweden